

# Scatter Tube - Instructions for Use



1. (left)

Remove lid from tube



2. (left)

Remove inner (white) tube and place on a flat surface with open end facing upwards

3.

Fill the white tube with ashes  
(using a funnel if required)



4. (left)

Squeeze a generous line of glue around the **inside** circumference of the outer tube (the one that is colour printed & has a hole in the base) approximately 2.5 cm / 1 inch below the rim



5. (left)

Line up the openings of both tubes and push the outer tube downwards slowly, to allow air to escape through the vent hole



6. (left)

Once the tubes are firmly in place, attach the sticker provided over the vent hole.

PLEASE NOTE – it is important to attach the sticker at this point in the assembly to prevent any leakage of cremains through the vent hole when the tube is returned to its upright position



7. (left)

Turn the sealed tube over and place the lid on, ensuring that any pattern is aligned



8. (left)

To scatter ashes, take the lid off and push out the perforated disc